

primacare seating | product specification

Wood Frame Patient Seating

Models GC3631W, GC3632W, GC3636W, GC3655W & GC3657W

Medium Back Chair Dimensions (Model GC3631W)

Overall Depth	27 in / 686 mm
Overall Width	25 in / 635 mm
Overall Height	36.5 in / 927 mm
Seat Depth	17.5 in / 445 mm
Seat Width	20.5 in / 521 mm
Seat Height	18 in / 457 mm
Back Height - From Seat	18 in / 457 mm
Armrest Clearance	20 in / 508 mm
Arm Height - From Seat	8.5 in / 216 mm
Product Weight	GC3631W 44 lbs / 20.0 kgs GC3631WCA 54 lbs / 24.5 kgs
Shipping Cube	17.5 ft ³ / 0.50 m ³

High Back Chair Dimensions (Models GC3632W & GC3655W)

Overall Depth	27 in / 686 mm
Overall Width	25 in / 635 mm
Overall Height	48.5 in / 1232 mm
Seat Depth	17.5 in / 445 mm
Seat Width	20.5 in / 521 mm
Seat Height	18 in / 457 mm
Back Height - From Seat	30 in / 762 mm
Armrest Clearance	20 in / 508 mm
Arm Height - From Seat	8.5 in / 216 mm
Product Weight	GC3632W & GC3655W 50 lbs / 22.7 kgs GC3632WCA & GC3655WCA 58 lbs / 26.4 kgs
Shipping Cube	27.5 ft ³ / 0.78 m ³

Hip Chair Dimensions (Model GC3636W & GC3657W)

Overall Depth	GC3636W 26 in / 660 mm GC3657W 25 in / 635 mm
Overall Width	GC3636W 23 in / 584 mm GC3657W 28 in / 711 mm
Overall Height	GC3636W 40.5 in / 1029 mm GC3657W 41 in / 1041 mm
Seat Depth	17.5 in / 445 mm
Seat Width	GC3636W 19 in / 483 mm GC3657W 24 in / 610 mm
Seat Height	GC3636W 25.5 in / 648 mm GC3657W 26 in / 660 mm
Back Height - From Seat	15.5 in / 394 mm
Armrest Clearance	GC3636W 19 in / 483 mm GC3657W 24 in / 610 mm
Arm Height - From Seat	7 in / 178 mm
Product Weight	GC3636W 47 lbs / 21.4 kgs GC3636WCA 52 lbs / 23.6 kgs GC3657W 58 lbs / 26.4 kgs
Shipping Cube	20 ft ³ / 0.57 m ³

Contact sales representative for more information.

Features

- Wall saver leg design prevents chair back from contacting walls before legs contact baseboards
- Integrated lumbar support
- Solid wood armcaps
- Complementing tables are available
- Easy grip forward extending armcaps



GC3632WCA (closed arms)



TRADE SHOWROOM

Showroom 33, Level 1, 69 O'Riordan Street, Alexandria NSW 2015
1300 724 174 | info@kezu.com.au

primacare seating | product specification

Features (continued)

MODELS GC3636W & GC3657W

- Hip chair is designed to assist patients recovering from hip surgery using wider arm clearance, higher seat height and foot rest bar

Options

- Wood frame available in several finishes
 - Wood armcaps are available in any standard GLOBALcare wood finish
 - Optional SSU armcaps are available in several colours
- MODELS GC3631W, GC3632W & GC3655W

- Flex back models are available with a torsion control mechanism allowing the back to rock back 14 degrees
- Wheels can be added to rear wheels for easy rearranging
- Under arm space is open, as standard, but closed arms are available for models in matching upholstery (CA models)
- Optional SSU armcaps are available in several colours

COM Yardage

Yardage is based on unmatched materials with widths of 54 inches for seating

MODEL GC3631W

- Full Unit: 1.75 yards
- Back: 1.15 yards
- Seat: 0.60 yards

MODEL GC3632W

- Full Unit: 2.25 yards
- Back: 1.65 yards
- Seat: 0.60 yards

MODEL GC3636W

- Full Unit: 1.50 yards
- Back: 0.98 yards
- Seat: 0.52 yards

MODELS GC36##WCA (closed arms)

- GC3631WCA Unit: 2.77 yards
- GC3632WCA Unit: 3.00 yards
- GC3636WCA Unit: 2.00 yards
- GC3655WCA Unit: 3.25 yards

Infection Control

- No Velcro on seat
- Seam sealing option
- Zipper sealing option
- Waterfall cleanout between seat and back cushions.
- Metal mesh seat pan
- Optional SSU arm caps are cleanable and non-porous

- For proper cleaning and disinfecting practices, the textile selection needs to be identified. It is vital that following any chemical application a clear water wipe down occur to avoid chemical build up that will lead to deterioration of the textile. Contact Global should information on using a specific disinfectant be required

On Site Repair and Replacement

- All components are field replaceable including seat, back, armcaps, and arm frames
- Arm frame are interchangeable allowing for on-site conversion from wood to steel, open arm frames to/from closed arm frames, and single seating to/from ganged seating (ganged seating only available for some models)
- Armcaps are interchangeable allowing for on-site conversion from wood armcaps to SSU armcaps

Construction (Overall Frame)

- All connections are metal-to-metal. Primary seat arm connection uses patent pending die-cast zinc connectors
- Arm frames use solid hardwood construction

Construction (Armcaps)

- Solid hardwood armcaps
- A formed steel insert inside armcap ensures a metal-to-metal connection to arm frame

Construction (Seat)

- 14 gauge rectangular tube seat frame
- Welded wire mesh seat deck

Construction (Back)

- ¾ in (19 mm) thick molded veneer back

Construction (Glides)

- Non-marking, black, polypropylene/polyethylene glides

Upholstery

- Zippered seat cushion
- Seat cushion hooks to underside of seat deck and back rail using proprietary C-clip fastener
- Back cushion hooks to underside of back using proprietary C-clip fastener



TRADE SHOWROOM

Showroom 33, Level 1, 69 O'Riordan Street, Alexandria NSW 2015
1300 724 174 | info@kezu.com.au

primacare seating | product specification

Foam

MODELS GC3631W, GC3632W & GC3655W

- Seat and back cushions have 3.5 in (89 mm) thick molded urethane foam

MODELS GC3636W & GC3657W

- Seat cushion is 2.5 in (64 mm) thick Ultracell foam.
Density: 2.6 lbs, ILD: 35
- Back cushion is 2.25 in (57 mm) thick Ultracell foam.
Density: 1.9 lbs, ILD: 22

Weight Capacity

Designed for an active weight capacity is 350 lbs per seat.

Warranty

Lifetime warranty on all components to the original purchaser except the following:

- 5 year warranty on foam and textiles
- Warranty applies only to single shift, standard commercial usage (8 hours/day, 5 days/week)

Fire Rating

All textiles and foam is tested and certified, meeting California Technical Bulletin 117 (CAL 117) standards.

Environmental

View [Environmental Data Sheets](#) online. All foam is produced without using any ozone depleting chloro-flouro chemicals.

Awards/Certifications

- Meets or exceeds all applicable BIFMA standards for safety and durability
- Manufactured in ISO 9001 and 14001 certified facilities

Please visit globalfurnituregroup.com for additional product information including environmental certifications.



TRADE SHOWROOM

Showroom 33, Level 1, 69 O'Riordan Street, Alexandria NSW 2015
1300 724 174 | info@kezu.com.au